

HP Documentation

HP 9000 Model 360 Owner's Guide

System Shutdown

Perform an orderly shutdown of the operating system. Reference the Owner's Guide for detailed instructions. Disconnect the system power cable.

Remove the CPU Card

Remove the HP 360 CPU card from the computer using the ejector handles. The HP 360 CPU has one brown and one black ejector handle. Slide the HP 360 CPU card out of the computer.

Memory Connectors

The 150-pin connector in the middle of the HP 360 CPU card is the memory connector.

3 Position Switch

The 3 position switch is used to specify the amount of memory on the card. The valid settings for this switch are as follows:

#1	#2	#3	Configuration
ON	OFF	OFF	4 Megabytes
OFF	ON	OFF	8 Megabytes
ON	ON	OFF	12 Megabytes
OFF	OFF	ON	16 Megabytes

The memory is shipped with this switch set to specify the amount of memory installed on the card. The setting of this switch would be modified only if you subsequently increase the amount of memory on the memory daughter card.

Metal Standoffs

The memory card is shipped with four metal standoffs that are used to secure the memory card to the HP 360 CPU card. The screws and lockwashers in the metal standoffs on the front of the memory card must be removed before installing the memory card.

Install Memory

Plug the memory card into the connector on the HP 360 CPU card. Be careful to align the connectors so that they mate successfully. If you align the connectors correctly, the standoffs will match up with the screw holes on the HP 360 CPU card.

Secure the memory card to the CPU card by screwing the screws and lockwashers from the back of the CPU card into the standoffs on the memory card. The lockwashers are positioned on the back of the CPU card next to the head of the screws.

Replace the CPU Card

Slide the CPU card with the attached memory daughter card back into the chassis. Connect any cables that were removed from the CPU I/O connectors.

Verify the New System Memory

Power up the system. Verify that the total system memory is correct. Call Newport Digital if you have any questions..

Newport Digital

14731 Franklin Ave, Tustin, CA 92780

714 730-3644 (Fax) 714 730-3951