

HP Documentation

HP 9000 Model 712 Owner's Guide (A2615-90616)

System Shutdown

Perform an orderly shutdown of the HP-UX operating system. Reference the Owner's Guide for detailed instructions. If the system is connected to an UPS, put the UPS output switch in the OFF (0) position. Disconnect the system power cable and the power cord of any peripheral devices from the ac wall outlets or UPS.

Open the Unit

Release the two locking tabs at the rear of the system unit by moving each toward the outside of the system unit, then push them forward until the top cover is released. Carefully slide the cover forward an inch or two and then carefully lift it off to open the system unit. Set the cover to one side.

Install Memory Cards

Attach the ESD Wrist Strap using the instructions on the 3M package. The motherboard has one slot for an add-on VRAM card. The slot is located between the eight RAM slots and the GSC slot. The VRAM slot is labeled J8. Position the VRAM card so that the notched section in the gold fingers mates correctly with the connector on the motherboard. Firmly press the card into the connector. It should snap into the connector.

System Reassembly

Place the cover assembly on the system unit approximately one inch from the rear. Push down on the center rear edge of the cover and slide it towards the rear of the system unit until the locking tabs engage. Reconnect the power cords.

Configure Monitor Type

Power up the system. Configure your workstation for monitor type 1 (1280x1024 72Hz) as described in the "Changing Your Monitor Type". There are two ways to configure your workstation to support a different monitor type: Setting the Monitor Type from the Boot Administration Mode, and Setting the Monitor at Power Up. Reference the 712 Owner's Guide for a detailed description.

Verify the New System Memory

Verify that the system has the correct amount of VRAM installed. If you have any questions call Newport Digital.

Newport Digital