

HP Documentation

HP Entria Hardware Installation Guide
HP Envizex Hardware Installation Guide

System Shutdown

Perform an orderly shutdown of the system. Power the system down. Disconnect the power cord and the other I/O cables.

Open the Unit

Attach the ESD Wrist Strap using the instructions on the 3M package.

Set the system on its bottom on an antistatic mat. Locate the two plastic tabs on the back of the computer. Depress both tabs and gently remove the plastic cover. Locate the two black handles on the back of the metal cover. Pull up on both handles. Remove the metal cover.

Install Memory

The Entria has 2 memory slots. The Envizex has 4 memory slots. The SIMMs can be installed in any order and they can be mixed sizes. The SIMM must be installed in the slot in the correct orientation. The module has a notch on one end of the gold fingers. The socket has a tab at the bottom of the clip on the left end. The notched end of the SIMM must be aligned with the tab in the socket.

System Reassembly

Place the metal cover on the system unit. Firmly press the two black handles down. Secure the top plastic cover on the system. Gently press the cover down so that the plastic tabs are seated. Reconnect the power cord and the other I/O cables.

Verify the New System Memory

Power up the system. Verify that the system indicates the proper amount of memory during the power-on RAM test. Call Newport Digital if you have any problems.